DIY HOUSE NUMBER

MAKE YOUR ADDRESS POP

Ready to boost your curb appeal AND make it easy for friends and family to spot your house? This DIY project will help sharpen your saw skills, can easily be customized to your own style , and gives your home a beautiful finishing touch. It's a DIY accomplishment that you and anyone passing by your home will get to admire every day.

STEPS

BUILDING THE SIGN BASE (FIG.A)

1. Gather materials and necessary Worx tools.
2. Determine the desired length of your sign based on the amount of address numbers and the location your sign will be mounted to. Then determine the desired size and spacing of your numbers. Once you know how long your sign needs to be, take the larger piece of wood and cut it to the appropriate length by making a crosscut using a miter saw or the Worx Versacut Compact Circular Saw.
3. Next, determine how wide you'd like your sign to be and if necessary, use the BladeRunner Portable Tabletop Saw and fence to cut (rip) along the length of your board.
4. Now that you have your address placard cut to size, use the Worx Sandeck Multi-Sander to briefly smooth the surface of the wood (150 grit will do). Once smooth, wipe free of dust and paint or stain to your liking and set aside to dry.

MAKING THE NUMBERS (FIG.B)

5. Take the other piece of wood and freehand draw or use a stencil to trace the shape of your first address number onto the wood.
6. Make sure your workpiece is clamped firmly to the Worx Pegasus Work Table with only the piece you will be cutting out, hanging over the edge.
7. Using the Worx Axis Cordless Jigsaw, cut out your first number, making sure to stay just on the outside of the lines you drew.
8. Set that number aside and re-clamp your workpiece with your next number hanging over the table. Repeat for as many numbers you need. It is a good idea to have a little extra wood in case you mess up on any of the numbers and need to re-cut.
9. Once all numbers are cut, you will need to sand them to smooth out the rough edges.
10. Once they are sanded and clear of dust, take your spray paint and coat all address numbers. Allow to dry properly before handling.
11. Once the sign and numbers are dry, you will use wood glue (optional) and the brad nailer to attach them to your placard. Align the numbers and begin to attach them by spreading a small amount of wood glue to the back of the number, hold number in place with one finger, while using the cordless brad nailer to fire a nail into the top and bottom of each number.
12. Wipe away any excess glue that may squeeze out with a damp cloth before it dries.
13. Place address sign in desired location, stand back, admire your handiwork!

RECOMMENDED MATERIALS

- **(1)** 1 piece of scrap wood that is approximately .75" thick (minimum 5" x 12" board to be used for the placard)
- **(1)** 1 piece of scrap wood from which to cut out numbers (can be more narrow, 3"x12")
- 1" brad nails, wood glue (optional)

TOOLS

- Pegasus Folding Worx Table *(WX051)*
- BladeRunner Portable Tabletop Saw *(WX572L)*
- 20V Brad Nail Gun *(WX840L – new product coming soon!)*
- 20V Power Share Axis Cordless Reciprocating & Jigsaw *(WX550L)*
- Versacut 3-3/8" Compact Circular Saw *(WX420L)*
- 20V Power Share Sandeck Multi-Sander *(WX820L)*
- Clamps
- Pencil
- Number stencils

(FIG.A)

(FIG.B)